



# RM69

## Brake Tubing Reamer

**THE RIGHT  
WAY TO  
PREP TUBING**



### Prepare Tubing For Flaring In Seconds

- Deburr 3/16", 1/4", 5/16", and 3/8" tubing
- Advanced six-flute design produces smoother, cleaner tubing
- Eliminates additional labor due to bad flares
- Reduces wear on flaring tool punches



**After cutting,  
tubing needs  
deburring**



**Deburred tubing is  
smooth, ready for  
flaring**

1.800.390.3996 • phone: 330.745.3300 • fax: 330.745.3488 • [www.surrauto.com](http://www.surrauto.com)

 **WARNING: Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)**